

AC•THOR / AC•THOR 9s

Photovoltaic-Power-Manager for hot water and space heating

Operation Manual



Contents

1. Assembly	4
2. Commissioning	4
1. Select language	4
2. Select operating mode	4
3. Select control of the control (the signal source) for the AC•THOR	4
4. Temperature sensor assignment and activation	7
5. Save the settings	8
3. Controls and displays	9
Homescreen	9
Status symbol	10
Data logger	10
Status information on the display	11
Settings	12
Help	12
4. Operating modes	12
M1: Hot water	12
Explanation	13
Specific settings for operating mode M1	14
Temperature sensors (only with AC•THOR 9s)	15
M2: Hot water stratified charging	15
Explanation	16
Specific settings for operating mode M2	17
M3: Hot water 6 kW/18kW	18
Explanation	18
Load measurement on relays with my-PV Meter (recommended)	19
Specific settings for operating mode M3	20
M4: Hot water + Heat pump	21
Explanation	21
Specific settings for operating mode M4	22
M5: Hot water + Space heating	23
Explanation	24
Specific settings for operating mode M5	25
Temperature sensors	26
M6: Space heating	26
Explanation	27
Specific settings for operating mode M6	27
Temperature sensors	28
M7: Hot water + PWM	28

Explanation	28
Specific settings for operating mode M7	29
M8: Frequency mode	30
5. General settings	30
6. Web-Interface.....	33
Search for devices in the network.....	33
Systems without Internet access	34
Connect Web-Interface	35
Home (homepage).....	35
Data logger	36
Status information.....	37
Settings	38
Special setting possibilities in the Web-Interface	39
Special settings for operating mode M3 (6kW/18 kW)	39
Legionella boost outputs (only with AC•THOR 9s)	40
Control Settings.....	40
Measurement Settings	43
EV Function	45
Multi units	46
Cloud Mode	48
Debug-Mode.....	48
Help	48
7. Frequency control.....	48
Explanation	48
Specific settings for Frequency control.....	49
8. Potential-free input for external control	49
9. Modbus RTU connection for external control	50
10. Firmware update	51
Update from server	51
Manual Update.....	51
Update with SD card.....	51
11. Status codes	51
12. Temperature sensors: Assignment and function (only with AC•THOR 9s)	52
13. Fault temperature sensors	52
14. Error messages on the Display.....	52
15. Fault signals by the AC•THOR Logo.....	53

1. Assembly

Before placing into operation it is essential to read the assembly instructions provided with the device.

2. Commissioning

Commissioning takes place in a few steps and must be carried out when the AC•THOR is started for the first time or after resetting to factory settings.

1. Select language

Use the left and right arrow keys to see more options.

From firmware version a0020202 onwards, French or Spanish can be selected in addition to German and English.

2. Select operating mode

See chapter headed "Operating modes".

The selection can also be changed at a later date.

3. Select control of the control (the signal source) for the AC • THOR

Use the left and right arrow keys to see more options.



Besides the my-PV Meter and open communication protocols such as http, Modbus TCP, Adjustable Modbus RTU and Adjustable Modbus TCP, as well as frequency control, pre-set signal sources are available for many compatible manufacturers.

For certain compatible partners the choice between „Auto“ (automatic IP-search of the device) or „Manual“ (manual entry of the IP address of the source) is possible. If a control type with the addition "Manual" is selected, the next step is to set the IP address of the signal source.



In the case of a control mode with the addition "Manual", the IP address of the signal source must not change during operation (e.g. by a DHCP router), otherwise the AC•THOR will lose the control signal.

Signalsource	Hardware Interface	Comments
my-PV Meter Auto	LAN (RJ45, Ethernet)	Connection to my-PV Meter in the network is set up automatically. Setting up the connection may take up to a minute!
my-PV Meter Manual	LAN (RJ45, Ethernet)	Connection to my-PV Meter in the network is set up by entering the IP address manually.
my-PV Power Meter Direkt	Direct connection (RJ45, crossover network cable)	Connection to the my-PV Power Meter is established directly without a network. A crossover network cable must be used for this type of connection! No direct connection is possible with the my-PV WiFi Meter!
Adjustable Modbus RTU	Modbus RTU (RS485, A B GND)	Cannot be selected on the display, configuration is done in the web interface. Temporary network access (RJ45, Ethernet) is therefore required at least for commissioning. See chapter "Special setting possibilities in the Web-Interface". Connection diagram according to chapter 9. When controlling via Modbus RTU, the operating mode M7 cannot be used!

Adjustable Modbus TCP (Sunspec etc)	LAN (RJ45, Ethernet)	Cannot be selected on the display, configuration is done in the web interface. See chapter "Special setting possibilities in the Web-Interface".
Carlo Gavazzi EM24 Manual	LAN (RJ45, Ethernet)	Approved for meter type EM24 with Modbus TCP.
Digital Meter P1	Modbus RTU (RS485, A B GND)	Device connection requires the " Digital Meter P1Interface" from my-PV as hardware interface. See here . When controlling via Modbus RTU, the operating mode M7 cannot be used!
Fox ESS (Modbus RTU)	Modbus RTU (RS485, A B GND)	The control signal is received via Modbus RTU (RS485, A B GND)! Connection diagram according to chapter 9. When controlling via Modbus RTU, the operating mode M7 cannot be used! Tested by my-PV with Type H3.
Frequency	Mains connection	See chapter 7 Frequency control.
Fronius Auto / Manual Fronius Gen24 Manual Fronius Sunspec Manual	LAN (RJ45, Ethernet)	Smart Meter required. For Modbus control Sunspec must be activated.
GoodWe Manual	LAN (RJ45, Ethernet)	Works with GoodWe high-voltage hybrids that communicate via the GoodWe Wifi+LAN module via LAN using Modbus TCP. For systems with battery storage, a value of 290W feed-in is preset as the target value of the control; without a battery, the value can also be reduced.
Growatt (Modbus RTU)	Modbus RTU (RS485, A B GND) 	The control signal is received via Modbus RTU (RS485, A B GND)! Connection diagram according to chapter 9. When controlling via Modbus RTU, the operating mode M7 cannot be used! Growatt connection assignment for RS485:  Note: Inverters that are not SPH- UP may need to be updated to the latest firmware version to communicate via RS485, according to Growatt. To do this, send the Growatt serial number and a short explanation to service.de@growatt.com .
http	LAN (RJ45, Ethernet)	A description of this open protocol is available in a separate document, which will be provided on request.
Huawei (Modbus RTU)	Modbus RTU (RS485, A B GND)	The control signal is received via Modbus RTU (RS485, A B GND)! Connection diagram according to chapter 9. When controlling via Modbus RTU, the operating mode M7 cannot be used! If the Huawei Smart Dongle is used on the inverter, communication problems may occur with this type of connection. We therefore

		recommend using the control type "Huawei (Modbus TCP) Manual" if possible, especially if a battery storage unit is present!
Huawei (Modbus TCP) Manual	LAN (RJ45, Ethernet)	Works with Huawei devices that communicate via Modbus TCP, such as the Huawei Smart Dongle-WLAN-FE! Note: From dongle firmware SPC124, TCP must be activated locally via the Huawei app! Alternatively, the AC•THOR could also be controlled via Modbus RTU. If a battery storage is available, however, the "Huawei (Modbus TCP) Manual" must be used explicitly!
IME Conto D4 Modbus MID (Modbus RTU)	Modbus RTU (RS485, A B GND)	The control signal is received via Modbus RTU (RS485, A B GND)! Connection diagram according to chapter 9. When controlling via Modbus RTU, the operating mode M7 cannot be used! Tested by my-PV with IME Conto D4 Modbus MID.
Kostal PIKO IQ Plenticore plus Manual	LAN (RJ45, Ethernet)	Suitable electricity meters please refer to the Kostal descriptions. Modbus must be activated on the inverter.
Kostal Smart Energy Meter Manual	LAN (RJ45, Ethernet)	Device ID as set on the device. Modbus Settings – Modbus TCP – set “Enable TCP Slave” active
MEC electronics Manual	LAN (RJ45, Ethernet)	Approved for meter type MECmeter.
Modbus TCP	LAN (RJ45, Ethernet)	A description of this open protocol is available in a separate document, which will be provided on request.
QCELLS (Modbus RTU)	Modbus RTU (RS485, A B GND)	The control signal is received via Modbus RTU (RS485, A B GND)! Connection diagram according to chapter 9. When controlling via Modbus RTU, the operating mode M7 cannot be used! Tested by my-PV with Q.VOLT HYB-G3 5.0 kW 1P, baud rate 115200. According to information from Q CELLS, the devices in the Q.VOLT HYB-G3 series support RTU communication. The correct communication connection to the Q.VOLT HYB-G3 inverter can be found in the Q CELLS manual.
RCT Power Manual	LAN (RJ45, Ethernet)	-
Slave	LAN (RJ45, Ethernet)	Cannot be selected manually. See chapter “ Multi units”
SMA Direct meter communication Auto / Manual	LAN (RJ45, Ethernet)	This control type is available for the SMA Energy Meter and SMA Sunny Home Manager devices. If this control type is carried out by the Sunny Home Manager, the superordinate energy planning for the my-PV device is then not given. There is also no visualization in the Load Balance. However, the power control is then carried out significantly faster than with the control type “SMA Home Manager”.
SMA Home Manager	LAN (RJ45, Ethernet)	The power signal which the SMA Sunny Home Manager gives the my-PV device depends not only on the feed-in, but also on the superordinate energy planning.
SolarEdge Manual Alternative: SolarEdge Synergy for 2-unit Manual SolarEdge Synergy for 3-unit Manual	LAN (RJ45, Ethernet)	Modbus TCP must be enabled on SolarEdge. The communication usually works either via port 502 or 1502. According to the latest information from SolarEdge, this control only works when connected via LAN, not WLAN.

Solax (Modbus RTU)	Modbus RTU (RS485, A B GND)	The control signal is received via Modbus RTU (RS485, A B GND)! Connection diagram according to chapter 9. When controlling via Modbus RTU, the operating mode M7 cannot be used! Tested by my-PV with X1-Hybrid5.0-G4, baud rate 115200. According to information from Solax, the G4 units support RTU communication. The correct communication connection to Solax can be found in the Solax instructions.
Steca Auto	LAN (RJ45, Ethernet)	-
Sungrow Manual	LAN (RJ45, Ethernet)	Works with Sungrow devices that communicate via Modbus TCP.
Varta Auto / Manual	LAN (RJ45, Ethernet)	-
Victron Energy 1ph / 3ph Manual	LAN (RJ45, Ethernet)	With Modbus control, the excess power control can be selected according to one or three phases.



TIP: For many of these **and other manufacturers** there are separate instructions for the required settings. More information about compatible manufacturers can be found [here](#).



When controlled by an inverter, a feed-in meter is required in the system. The query of the inverter otherwise provides no data.



We ask for your understanding that we cannot do any binding support for third-party products. For questions about third-party products, please contact the technical support of the respective company.



Not every signal source is approved for hybrid systems with battery storage. If necessary, please contact the technical support of my-PV.



Operation with battery may require additional control parameters. In this case, please contact the technical support of my-PV.

4. Temperature sensor assignment and activation

A number is assigned to the sensor in the order in which it is selected. The selection can be deselected by tapping on the key once more.

To assign a sensor to the respective entry in the list, the serial numbers can be identified on a label attached to the sensor wire.



TIP: As the measuring value of the sensor is already shown in the selection list, an assignment can alternatively also be made by simply altering the temperature on the sensor.



TIP: The use of a sensor is not necessary if the optional boost backup or the legionella programme are not used and the heat generator is switched off by a thermostat!

5. Save the settings

By saving the settings the commissioning for the use of excess power is finished. Additional functions, such as the optional boost backup, must be set separately.

3. Controls and displays


Homescreen



The "Home" button always returns you to the home screen. The upper bar shows the current date, time, the unit number and the operating mode (mode M1 – Mx). On the right, symbols show the unit's current status.

The contents of the home screen vary according to the operating mode and shows how much power the AC•THOR is currently feeding into the load. Depending on how many, if any, temperature sensors are defined, the measured values are also shown.


Homescreen AC•THOR:



Homescreen AC•THOR 9s:

With the AC•THOR 9s, the power display consists of three bars.

Load output Out-3
Load output Out-2
Load output Out-1



If several temperature sensors are used, the sensor number is displayed.



The button "Single boost" only appears in hot water operating modes if the function for ensuring a minimum temperature is activated. Actuating the button starts a once-only boost backup mode. This can also be deactivated while it is in operation.

If the boost backup is actuated automatically based on the day of the week, time of day or temperature, it cannot be deactivated by using the button.

Status symbol



Lights up = set temperature reached



Flashes = stand-by, waits for excess



Lights up = heats with PV excess. Flashes = boost backup mode



Lights up = no control signal



Lights up = physical connection to the RJ45 network connection is intact



Lights up = no intact physical connection to the RJ45 network connection



Block active

Data logger



Recorded production data, meter values and temperatures can be read off at any time. The respective values can be selected using the "Open" button. These can be presented in the three views of the current year, month or day using the "Calendar" button.



TIP: Type directly in the diagram on the individual bars to present the data in their next level of definition and on the button of the data logger again to return to the previous level.

The following data can be displayed:

Total power: Shows the total power figures for all the connected loads. The orange bars indicate the PV excess power used, the pink bars the proportion of grid energy when the optional temperature boost backup is active.

Meter: indicates the value of the total power drawn from the grid (blue) including household loads and grid feed-in (orange) at the metering point.

Power 1: shows the power data for load 1.

Power 2: shows the power data for load 2.

Temperature 1-4: shows the data of the temperature probe.

Status information on the display



The data of all variables relevant to the operation are shown in a list.

Output: shows the current output of the AC•THOR power unit.

Meter: shows the current data for the meter at the measuring point. A positive value shows drawing from the grid, a negative value, feeding into the grid.

PV: If a corresponding measuring point has been set in the Web-Interface under Setup, the value of the PV power is available here. See Measurement Settings.

Load: shows the nominal power of the load (at 230 V) which is currently being supplied by the AC•THOR output unit. This value can be determined from an output of 500 W.

With AC•THOR 9s, the load status (0 or 1) at the three outputs is displayed at this point.

If "none" or "0" is displayed even though a load is connected, the cause may be a thermostat that has been switched off or a safety temperature limiter that has been triggered.

Temperature 1: Current data probe 1

Temperature 2: Current data probe 2

Temperature 3: Current data probe 3

Temperature 4: Current data probe 4

IP: shows the current IP address of the AC•THOR.

Ctrl IP: shows the current IP address of the signal source. Shown in addition in the line below is the designation of the signal source and the current measured value. A positive value shows drawing from the grid, a negative value, feeding into the grid.

Status: Shows the unit's current status. See chapter "Status codes".

For AC•THOR 9s the number consists of two parts. On the left the status code of power unit AC•THOR 9s, on the right the status code of power unit AC•THOR.

Grid voltage: shows the current input voltage at the AC•THOR (only with AC•THOR)

Grid power: shows the current input power at the am AC•THOR (only with AC•THOR)

Output voltage: shows the current output voltage of the AC•THOR (only with AC•THOR)

Power 1: Power at output Out-1 (only with AC•THOR 9s)

Power 2: Power at output Out-2 (only with AC•THOR 9s)

Power 3: Power at output Out-3 (only with AC•THOR 9s)

Frequency: shows the current grid frequency.

Temperature output unit: shows the current temperature of the AC•THOR power electronics.

Fan: shows the current speed setting of the internal fan.

Serial number: shows the unit serial number.

MAC address: shows the MAC address of the unit.

Version: shows the current firmware version of the unit.

Version power stage: shows the current firmware version of the AC•THOR output unit.

For AC•THOR 9s the firmware version of the PS consists of two parts.

pXXX: Power stage AC•THOR

sXXX: Power stage AC•THOR 9s

Device number: shows the unit number set. This is also visible on the home screen.

Operating mode: shows the operating mode set (M1 – Mx). This is also visible on the home screen.

Latest firmware: shows the latest firmware version, or "current" is displayed.

Update status: Ok, loading (number of files), or waiting for installation

Output unit update status: Ok, loading, or waiting for installation

Cloud Status: Regardless of whether the cloud mode is active or not, it is displayed whether the cloud server my-PV.LIVE is reachable. If the info "99, Timeout" is displayed at this point, please send the 16-digit serial number to support@my-pv.com.

Ethernet (E) Firmware: Shows the status of the update progress when a new version is loaded.

Power stage (P) Firmware: Shows the status of the update progress when a new version is loaded.

Power stage 9s (S) Firmware: Shows the status of the update progress when a new version is loaded.

Relay status: shows the current status of the switch output (0 or 1).

For AC•THOR 9s this number has four digits. The first digit shows the status of the switch output (0 or 1), the second digit whether Out-3 is switched (0 or 1), the third digit whether Out-2 is switched (0 or 1) and the fourth digit shows the output that is currently supplied by the power stage (1, 2 or 3).

Settings



See chapter "General settings" for general unit settings, also chapter "Operating modes" for settings specific to the respective operating mode.

Help



After activation, brief information on the current view appears on the display. In the web interface the button leads to the online Operation Manual which corresponds to the firmware version installed.

4. Operating modes



You will find wiring diagrams for the respective operating modes and for wiring three-phase heating elements in the assembly instructions supplied with the AC•THOR, as well as in the latest version at any time on www.my-pv.com.

M1: Hot water

AC•THOR: Hot water with a single-phase immersion heater

AC•THOR 9s: Hot water with a three-phase immersion heater or with 3 single-phase immersion heaters



TIP for AC•THOR:

A single-phase heating element does not necessarily have to have 3kW power. Of course, smaller outputs such as 2kW are also possible!



TIP for AC•THOR 9s:

A three-phase heating element does not necessarily have to have 9kW power. Smaller outputs such as 4.5kW, 6kW or 7.5kW are also possible! Likewise, three single-phase elements can have a power of less than 3kW!

Explanation

In this operating mode, an electric heating element is supplied linearly with excess PV energy. It can be fitted with a bimetal thermostat to switch off when the temperature for which it is set is reached. Otherwise the my-PV temperature sensor is to be used.



With AC•THOR 9s in operation with three single-phase heating elements, bimetal thermostats must be present on all three immersion heaters!

Optionally, the AC•THOR can also take over guaranteeing the hot water temperature. For this, the my-PV temperature sensor is to be used.



The my-PV temperature sensor is in all cases to be installed in the storage tank above the heating element to provide a reliable reading!

The screenshot shows the AC•THOR home screen with the following elements:

- Top status bar: 03.05.18, 15:14:53, ACTHOR 1 - M1, and a signal strength indicator.
- Temperature display: A large red-bordered box highlights "23.1°C". To its right is a vertical color gradient bar.
- Power output display: A yellow progress bar is shown above the text "Heating Power 2075W". To its right is a red-bordered box containing a wavy line icon.
- Bottom navigation bar: Contains icons for a bar chart, information, home, settings, and help.

Labels on the left side of the screenshot:

- Data my-PV temperature sensor (pointing to the temperature display)
- Current power output (pointing to the power bar and text)

Text on the right side of the screenshot:

- Single-Boost Starts a once-only boost backup mode (button only appears if boost backup is activated) (pointing to the wavy line icon)

Centered below the screenshot: Homescreen



TIP: With the hot water boost backup, limit the use of grid power by avoiding the switch-off at maximum temperature. To do this, set the value higher than the cut out temperature on the immersion heating element thermostat and site the temperature sensor between the immersion heating element and the top edge of the storage tank. In this way, in boost backup mode only the volume above the sensor will be heated to the minimum temperature, while when there is

excess PV, the entire contents above the immersion heating element will be heated.

Specific settings for operating mode M1

Hot water 1 temperatures

Adjustable is the maximum permitted temperature to be reached at the my-PV temperature sensor (factory setting = 60 °C). This has nothing to do with a bimetal thermostat which may be installed!



If the cut out temperature of an immersion heating element with a bimetal thermostat is set too low, the AC•THOR may possibly be unable to reach the desired temperature!

If the optional automatic temperature boost backup is shown "On" in the window on the right (factory setting "Off") or the relay output has been selected, a minimum temperature can then be set (factory setting 50 °C).

Automatic temperature boost backup "On":

The AC•THOR can ensure a minimum temperature at the my-PV temperature sensor through the immersion heating element connected. This is supplied with maximum power.

Relay output:

Alternatively, the minimum temperature can be maintained by enabling an external heat source. Enablement is by means of a potential-free contact. For details of wiring the potential-free contacts, please refer to the assembly instructions in the chapter "Connections".



TIP for AC•THOR (not AC•THOR 9s):

If as an external heat source a second immersion heating element (maximum 3 kW) is used, it can be suitably connected up for 6 kW operation. This differs from the 6 kW operating mode in that here the second immersion heating element is only used for temperature boost backup and not as an extension to the normal control range!

Hot water 1 min switching times

This setting can be selected when the temperature boost backup is "On" under "Hot water 1 temperatures", or when the relay output has been selected.

There are two time windows available to maintain the minimum temperature on the my-PV temperature sensor. Start and finish can each be defined at full hours. Factory settings suggest switching times of 5 to 11 pm and 5 to 7 am.



TIP: Restrict the times when the minimum temperature has to be maintained to mornings and evenings, to increase your own PV consumption through the day!



Start hour and stop hour refer to the same calendar day. If a time window is defined over midnight, hot water backup will not start!



If the adjusted start-hour is after the stop-hour, hot water backup will not start!

Hot water 1 min weekdays

This setting can be selected when the temperature boost backup is "On" under "Hot water 1 temperatures", or when the relay output has been selected.

You can select the weekdays on which the minimum temperature has to be maintained. In the factory settings, all weekdays are activated.

Legionella program

For ensuring drinking water hygiene, a period can be specified by the end of which a set minimum temperature must again be reached after the last time it was reached. The number of days in this period can be set between 1 and 14. A time at which the legionella program is to start can also be specified. Factory settings are number of days 7, starting time 8 pm, temperature is 60 °C, the legionella program is "Off".


The immersion heating element is supplied with maximum power.

Load priority (only with AC•THOR 9s)

Defines the sequence in which the three load outputs are controlled.

Out 1-2-3: Standard, for a three-phase immersion heater.

Out 3-2-1: For stratified charging with three single-phase immersion heater.

 For Out 3-2-1, it is essential to observe the order of the load outputs according to the wiring diagram!

Boost output (only with AC•THOR 9s)

If boost backup is activated for AC•THOR 9s, it is possible to specify which load outputs are to be used for this purpose. All three outputs are activated at the factory.



TIP: If, for example, 3 single-phase heating elements are used, it may only be necessary to use the boost function on the top heating element. This keeps storage capacities free for excess energy, which can significantly improve the degree of self-sufficiency!

TIP: If not all three outputs of a three-phase heating element are used for boosting, control power is still available in case of excess energy!

Temperature sensors (only with AC•THOR 9s)

Optionally, three temperature sensors can also be used in the operation of three single-phase heating elements. The assignment must be made vice versa to the load outputs.

Note: One temperature sensor is always enclosed with the AC•THOR, other sensors must be purchased separately.

Load output / heater	Sensor number
Out-3 / Top	1
Out-2 / Center	2
Out-1 / Bottom	3

Excess power control and boost backup are then carried out individually for each heating element; the settings in " Hot water 1 temperatures" affect all three elements. If only one sensor is used, this only switches off the upper heating element, the other heating elements must be controlled via thermostats.

M2: Hot water stratified charging


AC•THOR: Hot water with two single-phase immersion heaters

AC•THOR 9s: Hot water with two three-phase immersion heaters

Explanation

In a water tank in this operating mode, two immersion heating elements are supplied successively and linearly with excess PV power. The upper element has priority. The aim is to reach the desired temperature at the tapping point as quickly as possible before further excess power heats up the remaining contents of the tank.

As soon as the upper immersion heating element reaches the target temperature the lower heater will be supplied. If no my-PV temperature sensor is used, the switch-over takes place via the thermostats of the heating elements, the AC•THOR then regularly checks whether the upper heating element is available again. If the my-PV temperature sensor is used, the changeover takes place when the temperature at the sensor reaches the set maximum value.


 Both heating elements must be equipped with a bimetal thermostat to switch off when the set temperature is reached!


With AC•THOR, the switchover between the single-phase heating elements takes place directly via the integrated relay (see wiring diagram). With the AC•THOR 9s, the relay operates a three-pole NC contact and a three-pole NO contact (see wiring diagram), which then switch over the three-phase heating elements.



TIP: It is also possible to control two immersion heating elements in separate tanks. The "upper" heater would then for instance be located in a drinking water tank, the "lower" heater in a buffer tank alongside it. However, the temperature sensor is absolutely necessary and must be fitted above the "upper" heating element!

Optionally, the AC•THOR can also take over the boost backup of the hot water temperature at the upper immersion heater. For this, the my-PV temperature sensor is to be used.

 The my-PV temperature sensor must in any event be installed in the hot water tank above the upper heater to provide a reliable reading!



The screenshot shows the AC•THOR homescreen with the following elements:

- Top status bar: 03.05.18, 15:23:02, ACTHOR 1 - M2, and a signal strength icon.
- Large central display: 21.0°C (highlighted with a red box).
- Right side: A vertical bar with a red arrow pointing up (highlighted with a red box) and a three-wavy-line icon (highlighted with a red box).
- Bottom section: A yellow progress bar (highlighted with a red box) and the text "Heating Power 1883W".
- Bottom navigation bar: Icons for signal strength, information, home, settings, and help.

Data my-PV temperature sensor

Current power output

Homescreen

An arrow shows which heater is currently being supplied. (upper or lower)

Single-Boost Starts a once-only boost backup mode (button only appears if boost backup is activated)

Specific settings for operating mode M2

Hot water 1 temperatures

Adjustable is the maximum permitted temperature to be reached at the my-PV temperature sensor (factory setting = 60 °C). This has nothing to do with a bimetal thermostat which may be installed!



If the cut out temperature of an immersion heating element with a bimetal thermostat is set too low, the AC•THOR may possibly be unable to reach the desired temperature!

If the optional automatic temperature boost backup is shown "On" in the window on the right (factory setting "Off"), a minimum temperature can then be set (factory setting 50 °C).

Automatic temperature boost backup "On":

The AC•THOR can ensure a minimum temperature at the my-PV temperature sensor with the upper heater. This is supplied with maximum power.

Hot water 1 min switching times

This setting can be selected when the temperature boost backup is "On" under Hot water 1 temperatures".

There are two time windows available to maintain the minimum temperature on the my-PV temperature sensor. Start and finish can each be defined at full hours. Factory settings suggest switching times of 5 to 11 pm and 5 to 7 am.



TIP: Restrict the times when the minimum temperature has to be maintained to mornings and evenings, to increase your own PV consumption through the day!



Start hour and stop hour refer to the same calendar day. If a time window is defined over midnight, hot water backup will not start!



If the adjusted start-hour is after the stop-hour, hot water backup will not start!

Hot water 1 min weekdays

This setting can be selected when the temperature boost backup is "On" under Hot water 1 temperatures".

You can select the weekdays on which the minimum temperature has to be maintained. In the factory settings, all weekdays are activated.

Legionella program

For ensuring drinking water hygiene, a period can be specified by the end of which a set minimum temperature must again be reached after the last time it was reached. The number of days in this period can be set between 1 and 14. A time at which the legionella program is to start can also be specified. Factory settings are number of days 7, starting time 8 pm, temperature is 60 °C, the legionella program is "Off".

The upper immersion heating element is here supplied with maximum power.

Boost output (only with AC•THOR 9s)

If boost backup is activated for AC•THOR 9s, it is possible to specify which load outputs are to be used for this purpose. All three outputs are activated at the factory.



TIP: If not all three outputs of a three-phase heating element are used for boosting, control power is still available in case of excess energy!

M3: Hot water 6 kW/ 18kW

AC•THOR: Hot water 6kW

AC•THOR 9s: Hot water 18kW

The AC•THOR 9s assumes two three-phase loads, three single-phase loads are not permitted in this operating mode!



TIP: In this operating mode, it is strongly recommended that both the AC•THOR control and the power measurement at the switched load are carried out with a my-PV Meter!

Explanation

In this operating mode, two heating elements are supplied with excess PV power in a water storage tank. One of them be regulated continuously variable, the other cuts in as soon as sufficient surplus PV is available. When this occurs, the first heater starts again from 0 with the power regulation. The total range of regulation is thus extended.

Both heaters have to be fitted with a bimetal thermostat to cut out when the set temperature is reached. The my-PV temperature sensor is to be used.

There are two operating modes:

A fixed threshold value can be set from which the second load is switched on. This threshold value is set in the web interface. See chapter "Special setting options in the web interface".

Alternatively, a my-PV Meter can be used to measure the power of the switched load. See chapter "Load measurement at relays with my-PV Meter (recommended)".



The power switched at the relay must not be greater than the power that can be controlled by the AC•THOR. Otherwise, unstable control behavior would be expected. Error 106 is displayed!



Third party control types may not be able to command the power up to 6kW / 18 kW!



If no my-PV Meter is used for power measurement at the switched load, the power display of the AC•THOR and the energy recording of the data logger cannot take this consumption into account!




The following applies to external control via "Modbus TCP", "http" or "SMA Home Manager" (not "SMA Direct Meter Communication"): An AC•THOR without an available load at the controllable output cannot be externally controlled in M3 operating mode. Since the load at the relay is not controllable, an unstable control behavior would be expected! This also applies if a my-PV Meter is used for power measurement at the switched load!

⚠ Multiple units (multi-mode): A slave without an available load at the controllable output cannot be controlled in the M3 operating mode in multi-mode. Since the load at the relay is not controllable, an unstable control behavior would be expected!
This also applies if a my-PV Meter is used for power measurement at the switched load!

⚠ The following applies to frequency control: This operating mode is not suitable for off-grid systems. my-PV recommends using several AC•THORs instead to increase the control range!

Optionally, the AC•THOR can also take over boost backup of the hot water temperature with both immersion heating elements.

⚠ The my-PV temperature sensor must in any event be installed in the hot water tank above the upper heater to provide a reliable reading!



The power display is automatically scaled by the additional power.

Load measurement on relays with my-PV Meter (recommended)

If a my-PV Meter is used for power measurement at the switched load, then the consumption is also shown in the power display and taken into account in the energy recording of the data logger.


The configuration is done in the web interface. See chapter "Special setting options in the web interface".

Scaling of the power display:

- With the AC•THOR to 3,000 watts + power measurement at the relay
- With AC•THOR 9s to 3,000 watts + power measurement at the relay / 3
A three-phase load is assumed at the relay (see wiring diagram).

Example AC•THOR 9s:

The power of the switched load was measured at 6,000 watts, the relay is switched. The three 3kW bars are each extended by 2kW (6kW/3).



Homescreen AC•THOR 9s in the web interface

- ⚠ When measuring the load on relays with a my-PV Meter, it is essential to follow the corresponding wiring diagram!
- ⚠ The relay is switched on for the first time when a surplus level of 3kW is exceeded with the AC•THOR or 9kW with the AC•THOR 9s. As soon as a measured value of the load is available, it is taken into account as a switching threshold in further operation!
- ⚠ If the nominal power at the switched load is reduced at a later point in time (e.g. due to a modification of the system), the switching threshold must be changed once to "Load on relay". Afterwards, the setting can be changed back to "Load measurement at relay with my-PV Meter". See chapter "Special setting options in the web interface".

Specific settings for operating mode M3

Hot water 1 temperatures

Adjustable is the maximum permitted temperature to be reached at the my-PV temperature sensor (factory setting = 60 °C). This has nothing to do with a bimetal thermostat which may be installed!

- ⚠ If the cut out temperature of an immersion heating element with a bimetal thermostat is set too low, the AC•THOR may possibly be unable to reach the desired temperature!

If the optional automatic temperature boost backup is shown "On" in the window on the right (factory setting "Off"), a minimum temperature can then be set (factory setting 50 °C).

Automatic temperature boost backup "On":

With both immersion heaters, the AC•THOR can assure a minimum temperature at the my-PV temperature sensor. These are supplied with maximum power.

Hot water 1 min switching times

This setting can be selected when the temperature boost backup is "On" under Hot water 1 temperatures".

There are two time windows available to maintain the minimum temperature on the my-PV temperature sensor. Start and finish can each be defined at full hours. Factory settings suggest switching times of 5 to 11 pm and 5 to 7 am.



TIP: Restrict the times when the minimum temperature has to be maintained to mornings and evenings, to increase your own PV consumption through the day!



Start hour and stop hour refer to the same calendar day. If a time window is defined over midnight, hot water backup will not start!



If the adjusted start-hour is after the stop-hour, hot water backup will not start!

Hot water 1 min weekdays

This setting can be selected when the temperature boost backup is "On" under Hot water 1 temperatures".

You can select the weekdays on which the minimum temperature has to be maintained. In the factory settings, all weekdays are activated.

Legionella program

For ensuring drinking water hygiene, a period can be specified by the end of which a set minimum temperature must again be reached after the last time it was reached. The number of days in this period can be set between 1 and 14. A time at which the legionella program is to start can also be specified. Factory settings are number of days 7, starting time 8 pm, temperature is 60 °C, the legionella program is "Off".

The immersion heaters are supplied with maximum power.

M4: Hot water + Heat pump

AC•THOR: Hot water with a single-phase immersion heater

AC•THOR 9s: Hot water with a three-phase immersion heater

Explanation

In this operating mode the electric immersion heating element of a heat pump is linearly supplied with excess PV power. This can be equipped with a bimetal thermostat to switch off when the set temperature is reached. Otherwise the my-PV temperature sensor must be used.



The my-PV temperature sensor must in any event be installed in the hot water tank above the upper heater to provide a reliable reading!


On exceeding a given excess power threshold, operation of the heating pump will be enabled. This threshold can be set. Similarly a minimum time for which this threshold must be exceeded. At the same time as the heat-pump is working, the additional excess power can be passed by the AC•THOR to the immersion heating element . This is activated in the factory settings.

After the defined excess power threshold has been exceeded for a specified time ($t_{P>}$), the heat-pump starts for the minimum operating time (t_{run}). This may also result in power being drawn from the grid!

When the minimum operating time has expired, the heat-pump remains enabled, provided there is still excess PV power available and the target temperature at the my-PV temperature sensor is not yet reached. If this now causes a fall in the excess PV power, the heat-pump will only be disabled after 60 seconds.

Once the heat-pump is disabled, it will not be reactivated for a period which can be set (t_{wait}).

Optionally, the AC•THOR can also take over guaranteeing the hot water temperature. This is carried out by enabling the heat-pump, when the immersion heating element will continue to be linearly supplied with excess.

 The target temperature of the heat-pump control is not to be set lower than the AC•THOR minimum temperature, as this could then no longer be guaranteed!



The screenshot shows the AC•THOR Homescreen with the following elements:

- Top bar:** Date and time (03.05.18, 17:06:56), unit name (ACTHOR 1 - M4), and status icons (three wavy lines and a green up arrow).
- Temperature:** A large display showing 23.0°C, highlighted with a red box.
- Time period:** A fan icon and text "t run 30 min" indicating the HP control time.
- Power output:** A horizontal bar chart showing power levels, with "Heating Power 1415W" displayed below it. A red box highlights the bar chart.
- Single-Boost:** A red button with three wavy lines, highlighted with a red box.
- Bottom bar:** Navigation icons for data, info, home, settings, and help.

Labels on the left side of the screenshot:

- Data my-PV temperature sensor
- Current power output

Labels on the right side of the screenshot:


- Time period and time counter value of the HP control
- Single-Boost Starts a once-only boost backup mode (Button appears only when the relay output is activated)

Centered below the screenshot: Homescreen

Specific settings for operating mode M4

Hot water 1 temperatures

Adjustable is the maximum permitted temperature to be reached at the my-PV temperature sensor (factory setting = 60 °C). This has nothing to do with a bimetal thermostat which may be installed!

 If the cut out temperature of an immersion heating element with a bimetal thermostat is set too low, the AC•THOR may possibly be unable to reach the desired temperature!

If the optional automatic temperature boost backup with relay output has been selected, a minimum temperature can then be set (factory setting 50 °C).

Relay output:

The AC•THOR can also maintain the minimum temperature at the my-PV temperature sensor by enabling the heat-pump.

Hot water 1 min switching times

This setting can be selected when the relay output is selected under "Hot water 1 temperatures".

There are two time windows available to maintain the minimum temperature on the my-PV temperature sensor. Start and finish can each be defined at full hours. Factory settings suggest switching times of 5 to 11 pm and 5 to 7 am.



TIP: Restrict the times when the minimum temperature has to be maintained to mornings and evenings, to increase your own PV consumption through the day!



Start hour and stop hour refer to the same calendar day. If a time window is defined over midnight, hot water backup will not start!



If the adjusted start-hour is after the stop-hour, hot water backup will not start!

Hot water 1 min weekdays

This setting can be selected when the relay output is selected under "Hot water 1 temperatures".

You can select the weekdays on which the minimum temperature has to be maintained. In the factory settings, all weekdays are activated.

Legionella program

For ensuring drinking water hygiene, a period can be specified by the end of which a set minimum temperature must again be reached after the last time it was reached. The number of days in this period can be set between 1 and 14. A time at which the legionella program is to start can also be specified. Factory settings are number of days 7, starting time 8 pm, temperature is 60 °C, the legionella program is "Off".

This enables the heat-pump and the immersion heating element remains in "excess" operation.

Relay thresholds

As switching threshold for a heat-pump, any output between 0 and 9,999 W can be set. Factory setting is 500 W. An alteration to this output threshold only becomes effective after the end of the current control cycle or after the AC•THOR is restarted.

Optionally, simultaneous control of the AC•THOR load output can be deactivated on the right of the screen.

Relay delay

A period in minutes is laid down ($t_{P>}$), during which the switching threshold above must at least be exceeded before the heat-pump is enabled. The factory setting suggests 15 minutes. After this, a minimum operating period (t_{run}) and a minimum pause duration (t_{wait}) can be set for the heat-pump. Factory settings suggest 30 minutes for both these values

M5: Hot water + Space heating

AC•THOR: Hot water + one heating zone

AC•THOR 9s: Hot water + two heating zones



Note for AC•THOR 9s as of Ethernet firmware version a0020806

Compared to previous versions, there is now the following advantage: If a minimum temperature must be ensured with maximum power at room heating 1 (output Out-1), then the AC•THOR 9s can still control power at outputs Out-2 (room heating 2) or Out-3 (hot water) during this time, provided the target temperature has not yet been reached at these and there is still surplus.

From version a0020806 onwards, a 2-pole changeover contact must be provided in the installation for this purpose, which is actuated by the potential-free contact of the AC•THOR 9s. For wiring details, please refer to the installation instructions enclosed with the unit. You can also find the latest information at any time at www.my-pv.com.

Note: A firmware update does not change the previous operating mode of already installed

Explanation

This operating mode is intended for buildings with hot water and space heating by electricity. Electrical heat sources are supplied with PV surplus one after the other linearly with power. The immersion heating element for the hot water supply takes priority. As soon as the hot water target temperature at the respective my-PV temperature sensor is reached, next the electric space heating is supplied until here too the target value at the my-PV temperature sensor is reached.

Optionally, the AC•THOR can also take over guaranteeing the hot water temperature.

Two my-PV temperature sensors are required for AC•THOR!

Three my-PV temperature sensors are required for AC•THOR 9s!

Note: One temperature sensor is always included with the AC•THOR, other sensors must be purchased separately.



The first my-PV temperature sensor is in any case to be sited over the heater in the hot water tank to provide a reliable reading!




For controlling the space heating, the respective my-PV temperature sensor is to be installed in a suitable place to provide a reliable reading!



TIP: When specifying room temperatures, to avoid using power from the public grid the minimum values for day and night should be set correspondingly low. See explanation "SH 1 temperatures".

Data my-PV
 temperature sensors
 Water temperature
 Room temperature 2
 Room temperature 1
 (sun = daytime
 operation)
 Current power
 output



Single-Boost
 Starts a once-only hot
 water boost backup
 (button only appears if
 boost backup is activated)

Homescreen

On the display a sun or moon symbol shows which time period is currently controlling the room temperature. Different minimum temperatures can be specified for day and night.

Specific settings for operating mode M5

Hot water 1 temperatures

The maximum temperature permitted to be reached at my-PV temperature sensor 1 can be adjusted (factory setting 60 °C). This has nothing to do with a bimetal thermostat which may be installed!



If the cut out temperature of an immersion heating element with a bimetal thermostat is set too low, the AC•THOR may possibly be unable to reach the desired temperature!

If the optional automatic temperature boost backup is shown "On" in the window on the right (factory setting "Off"), a minimum temperature can then be set (factory setting 50 °C).

Automatic temperature boost backup "On":

The AC•THOR can ensure a minimum temperature at the my-PV temperature sensor through the immersion heating element connected. This is supplied with maximum power.

Hot water 1 min switching times

This setting can be selected when the temperature boost backup is "On" under Hot water 1 temperatures".

There are two time windows available to maintain the minimum temperature on the my-PV temperature sensor. Start and finish can each be defined at full hours. Factory settings suggest switching times of 5 to 11 pm and 5 to 7 am.



TIP: Restrict the times when the minimum temperature has to be maintained to mornings and evenings, to increase your own PV consumption through the day!



Start hour and stop hour refer to the same calendar day. If a time window is defined over midnight, hot water backup will not start!



If the adjusted start-hour is after the stop-hour, hot water backup will not start!

Hot water 1 min weekdays

This setting can be selected when the temperature boost backup is "On" under Hot water 1 temperatures".

You can select the weekdays on which the minimum temperature has to be maintained. In the factory settings, all weekdays are activated.

Legionella program

For ensuring drinking water hygiene, a period can be specified by the end of which a set minimum temperature must again be reached after the last time it was reached. The number of days in this period can be set between 1 and 14. A time at which the legionella program is to start can also be specified. Factory settings are number of days 7, starting time 8 pm, temperature is 60 °C, the legionella program is "Off".

The immersion heating element is supplied with maximum power.

SH 1 temperatures (with AC•THOR 9s SH 1 und SH 2)

The maximum room temperature permitted to be reached at my-PV temperature sensor 2 or 3 (sensor 1 is for hot water) can be adjusted (factory setting 22 °C), as are the minimum temperatures which should be maintained in the day and night periods (factory setting 20 °C in each case).

SH 1 Switching times (with AC•THOR 9s SH 1 und SH 2)

Start and finish of the night period can both be adjusted with hours and minutes. The factory setting suggests the period between 10 pm and 5 am. This setting can be selected as desired for all days of the week with corresponding selection of the button alongside the time (MON-SUN, MON-FRI, SAT-SUN).

Temperature sensors

Sensor assignment AC•THOR:

Application	Sensor number
Hot water	1
Space heating	2

Sensor assignment AC•THOR 9s:

Excess power control and boost backup are then carried out individually for each load output.

Load output / Application	Sensor numb
Out-3 / Hot water	1
Out-2 / Space heating 2	3
Out-1 / Space heating 1	2

M6: Space heating

AC•THOR: One heating zone

AC•THOR 9s: Three heating zones

Explanation

In this operating mode an electric space heating is supplied linearly with excess PV power.

One my-PV temperature sensors are required for AC•THOR!

Three my-PV temperature sensors are required for AC•THOR 9s!


Note: One temperature sensor is always included with the AC•THOR, other sensors must be purchased separately.



To control the space heating, the respective my-PV temperature sensor is to be installed in a suitable location to provide a reliable reading!



TIP: When specifying room temperatures, to avoid using power from the public grid the minimum values for day and night should be set correspondingly low. See explanation "SH 1 temperatures".



Homescreen

On the display a sun or moon symbol shows in which time period the room temperature control is currently operating. Different minimum temperatures can be specified for day and night.

Specific settings for operating mode M6

SH 1 temperatures (with AC•THOR 9s SH 1, SH 2 and SH 3)

The maximum room temperature permitted to be reached at the my-PV temperature sensors can be adjusted (factory setting 22 °C), as are the minimum temperatures which should be maintained in the day and night periods (factory setting 20 °C in each case).

SH 1 Switching times (with AC•THOR 9s SH 1, SH 2 and SH 3)

Start and finish of the night period can both be adjusted with hours and minutes. The factory setting suggests the period between 10 pm and 5 am. This setting can be selected as desired for all days of the week with corresponding selection of the button alongside the time (MON-SUN, MON-FRI, SAT-SUN).

Temperature sensors

Sensor assignment AC•THOR:

Application	Sensor number
Space heating	1

Sensor assignment AC•THOR 9s:

Excess power control and boost backup are then carried out individually for each load output.

Load output / Application	Sensor numb
Out-3 / Space heating 3	3
Out-2 / Space heating 2	2
Out-1 / Space heating 1	1

M7: Hot water + PWM

AC•THOR: Hot water with a single-phase immersion heater

AC•THOR 9s: Hot water with a three-phase immersion heater



When controlling via Modbus RTU, the operating mode M7 cannot be used!

Explanation

In this operating mode, an electric heating element is supplied linearly with excess PV energy. In addition, the AC•THOR can send out a temperature-dependent PWM signal. This can control the speed of a pump.

This function was tested by my-PV with the pump types **Wilo Para PWM1 and PWM2** and **Wilo Varios PICO-STG**. For PWM2, the setting command xxx.xxx.xxx.xxx.xxx/setup.jsn?pwmt=2 must be entered in the URL of the webinterface. For other pumps, the function cannot be certified.




In this operating mode, two my-PV temperature sensors are required!

The output of the PWM signal starts when the target temperature + hysteresis is reached at sensor 2. The signal becomes stronger the further the target temperature + hysteresis is exceeded.

Optionally, the AC•THOR can also take over guaranteeing the hot water temperature. For this, a third my-PV temperature sensor is to be used.

Note: A temperature sensor is always included with the AC•THOR, other sensors must be purchased separately.



Specific settings for operating mode M7

Hot water 1 temperatures

Adjustable is the maximum permitted temperature to be reached at the my-PV temperature sensor (factory setting = 60 °C). This has nothing to do with a bimetal thermostat which may be installed!



If the cut out temperature of an immersion heating element with a bimetal thermostat is set too low, the AC•THOR may possibly be unable to reach the desired temperature!

If the optional automatic temperature boost backup is shown "On" in the window on the right (factory setting "Off") or the relay output has been selected, a minimum temperature can then be set (factory setting 50 °C).

Automatic temperature boost backup "On":

The AC•THOR can ensure a minimum temperature at the my-PV temperature sensor through the immersion heating element connected. This is supplied with maximum power.

Relay output:

Alternatively, the minimum temperature can be maintained by enabling an external heat source. Enablement is by means of a potential-free contact. For details of wiring the potential-free contacts, please refer to the assembly instructions in the chapter "Connections".



TIP for AC•THOR (not AC•THOR 9s):

If as an external heat source a second immersion heating element (maximum 3 kW) is used, it can be suitably connected up for 6 kW operation. This differs from the 6 kW operating mode in that here the second immersion heating element is only used for temperature boost backup and not as an extension to the normal control range!

Hot water 1 min switching times

This setting can be selected when the temperature boost backup is "On" under "Hot water 1 temperatures", or when the relay output has been selected.

There are two time windows available to maintain the minimum temperature on the my-PV temperature sensor. Start and finish can each be defined at full hours. Factory settings suggest switching times of 5 to 11 pm and 5 to 7 am.



TIP: Restrict the times when the minimum temperature has to be maintained to mornings and evenings, to increase your own PV consumption through the day!



Start hour and stop hour refer to the same calendar day. If a time window is defined over midnight, hot water backup will not start!



If the adjusted start-hour is after the stop-hour, hot water backup will not start!

Hot water 1 min weekdays

This setting can be selected when the temperature boost backup is "On" under "Hot water 1 temperatures", or when the relay output has been selected.

You can select the weekdays on which the minimum temperature has to be maintained. In the factory settings, all weekdays are activated.

Boost output (only with AC•THOR 9s)

If boost backup is activated for AC•THOR 9s, it is possible to specify which load outputs are to be used for this purpose. All three outputs are activated at the factory.



TIP: If not all three outputs of a three-phase heating element are used for boosting, control power is still available in case of excess energy!

M8: Frequency mode



From Ethernet firmware version a0020400 applies

The frequency mode is no longer a separate operating mode. Instead, frequency control is selectable as a signal source. This means that the operating modes M1 to M7 can now be used in AC off-grid systems.

A firmware update on a unit in "M8 frequency mode" automatically switches it to the operating mode "M1 hot water" and "frequency" is set as the signal source.

For more information, see chapter 7 Frequency control.

5. General settings

For settings specific to the different operating modes, please see the chapter "Operating modes". Under the settings these are accessed on the first sheet "Setup 1/X" and some of them on sheet two, "Setup 2/X".

Time zone: The time zone can be set for the time. In addition, summer time is activated for Europe.

Date: The date can be entered in the format dd.mm.yy.

Time: The time can be entered in the format hh:mm:ss.

NTP server: (NTP = Network Time Protocol) As long as the router provides an Internet, the AC•THOR draws its time information automatically from the Internet. However, the respective

time zone is not specified. NTP-Timeserver-address can be changed if necessary. The factory setting is 131.130.251.107.



With a direct connection from the AC•THOR to the my-PV power meter, there is no Internet connection. Hence the time cannot be taken!

IP DHCP/static: As standard, DHCP is activated, i.e., the unit will get an IP address from the router to which it is connected. This only works when the router is configured as a DHCP server. If no DHCP server is active in the grid or if a static assignment is required, a fixed IP address is needed.



The settings have to fit with the router, otherwise the device become invisible in the network!

IP address: can only be set when "Static IP" has been selected and there is no direct connection to the my-PV power meter.

Subnet mask: can only be set when "Static IP" has been selected and there is no direct connection to the my-PV power meter.

Gateway address: can only be set when "Static IP" has been selected and there is no direct connection to the my-PV power meter.

DNS server: can only be set when "Static IP" has been selected and there is no direct connection to the my-PV power meter.

Display duration: the number of seconds elapsing until the display is turned off can be set. A value between "10" and "250" seconds can be entered.

Display brightness: brightness of the display can be adjusted in ten steps.

Logo brightness: brightness of the illuminated AC•THOR logo on the unit can be adjusted in ten steps. "0" indicates that the logo will not be turned off

Control: In this section the choice of the signal source for the AC•THOR is made. See chapter "Commissioning".

Ctrl IP: The IP address of the signal source can be selected manually. For example, this is necessary when there are several compatible sources in the network and a special one of them should be chosen as the control system.

Control target value: here the set value of the power at the metering point is specified. A negative value means feed-in. The factory pre-set of the set-point is -50 W. This parameter can be freely chosen in a range between -9999 and +9999 W.


Sensors: Here the temperature sensor is selected for the operating mode. See chapter "Commissioning".

Operating mode: Detailed description will be found in the chapter "Operating modes".

Language: Apart from German, the following languages can be selected: English, French and Spanish.

Unit number: Shows the set unit number. This can also be seen on the Home screen.

Maximum power: This setting limits the output voltage of the AC•THOR. This results in a reduction factor of the nominal power of the load, i. the actual maximum output power depends on the rated power of the load. The maximum output voltage as a function of the parameter results from the following characteristic curve:



The value can be set on the display between 17 – 100 percent.



This setting is not taken into account in M3 operating mode.



Adjustment is generally only required if the rated load power is bigger than the power available for the AC•THOR.

(protection, inverter power in frequency mode)

Access level (only until Firmware-Version a0010103): according to user level (1 – 3), different setting possibilities are enabled on the AC•THOR. In level 3 all settings are enabled. As factory setting, this level is active. It is possible to restrict the setting options enabled.

Level 2 offers slightly restricted setting possibilities for experienced users. Some examples of settings which cannot be altered are those for communication, operating mode, basic settings, sensor assignment and control settings.

In level 1 the setting possibilities are limited to temperature specifications and switching times for space heating (only relevant in operating modes M5 and M6), as well as the brightness and duration of the display settings and brightness of the AC•THOR logo.

A password is required to be able to return to a higher level. The password for level 2 is "1970", that for level 3, "1965".

Power timeout: With this setting, the timeout of the AC•THOR (power timeout) can be set for several control types.

Hysteresis: switch hysteresis can be set for hot water and room heating. This does not cause too high a target temperature! After reaching the target temperature, the value is allowed to fall by the set amount before the heating process is restarted.

Hot water maximum temperature (factory setting 3.0 °C)

Hot water minimum temperature (factory setting 3.0 °C)

Space heating maximum temperature (factory setting 0.5 °C)

Space heating minimum temperature (factory setting 0.5 °C)

Error log: The table shown is intended for analysis by my-PV.

Factory settings:

Factory settings: tapping on the menu point resets the AC•THOR to its factory settings. This will cause all altered settings in the unit to be deleted!

CAUTION! No security confirmation is requested!

Check for new firmware:



Internet access is required!

Start check for new updates manually. When a new version is available, it will be stored on the SD card. This procedure takes several minutes. The AC•THOR will operate normally during this period.

Start firmware update: if a newer software version is present on the SD card, the update can be started manually. After the update, the unit will be restarted automatically.

Start power firmware update: if a newer output unit software version is present on the SD card, the update can be started manually. After the update, the unit will be restarted automatically. With AC•THOR 9s the update for both power stages is started.

6. Web-Interface

By means of a HTML file (required for Ethernet firmware version a0020000 or higher) data of the AC•THOR can be retrieved and adjustments can be made.



TIP: The Web-Interface offers much more extensive setting options than the AC•THOR Display!

Search for devices in the network




You can only access the web interface if the AC•THOR is in a network. If it has a direct connection to the power meter, this access is not possible!



If you cannot access the AC•THOR in the network, check the network settings on the display!

Expiry of the network connection:

1. After the connection using a patch lead the AC•THOR is assigned a dynamic IP address by the router. It can then be searched for in the network using the program "my-PV Scanner.exe" (included in the "Software package AC•THOR.zip" on www.my-pv.com). To do this, unpack the scanner program into a local directory.



2. If there are several my-PV devices in the network, the unit to be configured can be identified by the serial number (for AC•THOR see type plate on the back of the unit).
3. The web interface opens by double clicking on the respective search result. From firmware version a0020000 onwards, the required HTML file is downloaded from the Internet and stored in the same directory as the scanner program.




Scanning is performed via UDP port 16124. Firewalls (or specific router settings) may prevent the AC•THOR from being found.



TIP: You will also find the IP address of the AC•THOR on the display or in the DHCP list in the router!

Alternatively, the second scan program "Scan AC ELWA-E ARP.exe" can be used, which sends an ARP query to the router and displays the connected my-PV devices. Since the router takes some time to update the ARP table it may be that the ARP scan takes some time to show AC ELWA-E results.



From firmware version a0020000 onwards, the Web-Interface of AC•THOR is outsourced to an external HTML file. If the device is accessed directly via the IP address in the web browser, this view appears.

DE: Ab Version a0020000 erfolgt der Aufruf des AC•THOR Webinterfaces durch eigene HTML Datei, die einmalig lokal gespeichert werden muss.
 EN: From Version a0020000 the AC•THOR webinterface is accessed from a separate HTML file that needs to be stored locally once.
 FR: À partir de la version a0020000, l'interface web AC•THOR est appelée par son propre fichier HTML, qui doit être enregistré localement une fois.
 ES: A partir de la versión a0020000, la interfaz web de AC•THOR es llamada por su propio archivo HTML, que debe ser guardado localmente una vez.

[Download Webinterface](#)

DE: Alternativ kann das AC•THOR Webinterface auch direkt im Browser geöffnet werden.
 EN: Alternatively, the AC•THOR webinterface can also be opened directly in the browser.
 FR: L'interface web de la AC•THOR peut également être ouverte directement dans le navigateur.
 ES: Alternativamente, la interfaz web de AC•THOR también puede abrirse directamente en el navegador.

[Open Webinterface in Browser](#)

Follow the download link (above) and save the file locally, then open the file to access the Web-Interface. Alternatively, you can open the Web-Interface directly in your web browser (link below).



my-PV does not recommend to connect the AC•THOR to the Internet via port forwarding access!

Systems without Internet access



From Ethernet firmware version a0020000 applies:

To be able to access the Web-Interface of AC•THOR in systems without internet access, please download the required HTML file in advance via this link:


<http://www.my-pv.com/download/currentversionget.php>

Connect Web-Interface

If the Web-Interface is started via the scanner program (see chapter "Search for devices in the network", the connection to the device is established automatically.

From firmware version a0020202 onwards, the current Web-Interface allows the selection of French or Spanish in addition to German and English.


If the Web-Interface is started by calling the HTML file, the IP address range of the network in which the device is located must be set once. The entry is saved by the web browser, but the address range can be redefined at any time using the "IP Search Range" button.




Home (homepage)



The AC•THOR start page in the web browser gives the same information as the home screen on the display. Navigation using the symbols bar is carried out in the same way. Further information in the chapter "Control and display elements".



With device state "Off", the load control can be switched off.



A quick selection in the upper right corner allows direct access to the Web-Interface from other my-PV devices in the network. The button "Search Devices" scans the network for my-PV devices.



TIP: If the device search does not produce a result, the IP address can also be entered manually in the address line of the web browser.

URL: ... / my-PV Websetup 00XXX.XX.html?ip=XXX. XXX. XXX. XXX

Consider that the appearance and the scope of options can change with updated software versions.


Data logger



The AC•THOR data logger In the web browser gives the same information as the data logger on the display. The selection of values and time period is possible using the menu bar above the diagram. Further information in the chapter "Control and display elements".



TIP: Move the mouse over the bar and the exact values will be shown!



Orange bars indicate the proportion of energy that comes from the photovoltaic system, red bars indicate the proportion of optional boost-backup.

Status information



The status information in the web browser contains more details than that on the AC•THOR display.

Explanations can be found in the chapter "Status information on the display".

Depending on the operating mode and application, this representation varies.

AC-THOR State		
State:	1, Heating	
ACTHOR:	882	W
Solarpart:	882	W
Gridpart:	0	W
Output 1 Solarpart:	882	W
Output 1 Gridpart:	0	W
Output 2 Solarpart:	0	W
Output 2 Gridpart:	0	W
Load:	1	
Load nominal power:	2988	W
Relays state:	0	
Pump PWM:	0	%
Temperature 1:	25.1	°C
Temperature 2:	0	°C
Temperature 3:	0	°C
Temperature 4:	0	°C
HW Boost state:	0	
Next legionella boost:	-	days
Date:	28.07.21	
Time:	15:38:03	
Control state:	Conn. to Power Meter.	
	P=-29	
Block State:	0	
discovered my-PV Power Meter 1 ID:	1438514	
discovered my-PV Power Meter 1 IP:	192.168.2.16	
Meter + battery charging:	29	W
Feed-In point:	29	W
Voltage L1:	230	V
Current L1:	3.9	A
Output voltage power stage:	122	V
Mains frequency:	49.988	Hz
Temperature power stage:	30	°C
Fan speed:	0	
State power stage:	Running	
Cloud state:	4, Connected (0)	
Debug IP:	85.25.211.141	


Settings



The setting possibilities in the web browser are more extensive than those on the AC•THOR display. See next section "Special setting possibilities in the Web-Interface".

An explanation of the other general unit settings is included in the chapter "General settings".

An explanation of the other specific unit settings for the different operating modes is included in the chapter "Operating modes".




The choice of setting options varies depending on the operating mode.

Special setting possibilities in the Web-Interface

The following unit settings are only possible in the web interface and cannot be carried out on the AC•THOR display.

Special settings for operating mode M3 (6kW/18 kW)

The following parameters can be set on the web interface in operating mode M3 (6kW/18 kW).



Control tolerance: This value defines the reaction sensitivity of the AC•THOR relay to changes in the power input. The second heating rod is switched by the relay.

Load at relay: The control range of the AC•THOR is extended by this adjustable threshold value. When the threshold value is reached, the load on the relay is switched on and the AC•THOR starts controlling again from 0 watts at the controlled load.

Load measurement on relay with my-PV Meter: As an alternative to the static definition of the load at the relay, it can also be measured with a my-PV Meter. To do this, enter the device ID of the my-PV Meter. This can be found on the device.



TIP: If the AC•THOR control is also carried out with a my-PV Meter (recommended), a static IP address should be assigned for it and the control

type "my-PV Meter Manual" should be selected. Otherwise, the AC•THOR could confuse the signal source!



Legionella boost outputs (only with AC•THOR 9s)

With the AC•THOR 9s, a selection of the load outputs to be used in the Legionella program can be made in the web interface. All three outputs are activated in the factory.

▲ Legionella Protection

Avoidance of Legionella: Off

Legionellen-Boost Outputs: 1, 2 and 3

Activation Interval: 7 Days

Start Hour: 20

Target Temp: 60 °C

Save



TIP: If, for example, 3 single-phase heating elements are used and only one of them is in a drinking water storage tank, then the Legionella programme should only be used on this heating element!

Control Settings

▲ Control Settings

Control type: my-PV Meter Auto

ELWA Number >1: only 'Slave' selectable.

TIP: For many control types there are separate instructions for the required settings. More information can be found [here](#).

Control source IP address: 0 0 0 0

Control state:

Power timeout: 10 s

Control target: -50 W

Interval target value: Off On

Block start / stop hour: 0 0

Save

In this section the choice of the signal source for the AC•THOR is made.



A control type can only be selected if the AC•THOR has the factory preset device number 1. See "Basic settings".

The "**Interval target value**" function causes the AC•THOR to automatically change the target value of the control to another adjustable target value for a certain duration in an adjustable time interval. This can ensure that other applications with regulated surplus control are not deprived of surplus energy by the my-PV application.

Interval target value:	<input type="radio"/> Off
Interval target value: If active, a different target value of the control is used in the set time window.	<input checked="" type="radio"/> On
Interval target value of the control:	<input type="text" value="-1500"/> W
Interval	<input type="text" value="15"/> min
Duration of the interval target value:	<input type="text" value="60"/> s

This includes, for example, charging stations for electric cars that are neither directly nor indirectly connected to my-PV. Therefore, my-PV sets -1500W as the default for the interval target value. This corresponds to the minimum charging power of many electric cars. A further explanation can be found in the section "Compatibility with charging station without shared energy management" in the chapter "E-car function".

The function „**Block**“ allows to define a time window within AC•THOR must not run. Unlike the two time frames for hot water securing the transition to the following day is possible (Start Hour is higher than Stop Hour). For example, this function can be used to give an existing battery time for charging and to do the water heating subordinate.

The function blocks the surplus control, as well as the optional boost backup via the connected heat generator. It also applies to the switched load in operating mode M3.

The blocking time does not apply to the optional boost backup setting via relay, not to the external load in operating mode M4 and also not to the EV function.



Changes of the time settings are effective within one minute.

With the control modes "**Adjustable Modbus RTU**" and "**Adjustable Modbus TCP**" the AC•THOR receives the power-value in the feed-in point from an inverter or Modbus counter. The required communication registers shall be set according to the manufacturer's description.



With "**Adjustable Modbus TCP**" the control signal is received via network (RJ45, Ethernet)!



With "**Adjustable Modbus RTU**" the control signal is received via Modbus RTU (RS485, A B GND)! This control system is also configured via the Web-Interface. At least for commissioning, a network access is therefore temporarily necessary, but this can be removed after configuration!



TIP: A simple network router is part of the normal tools of a craftsman these days. If you always have your own router with you, you are not dependent on network access at the sight.

An Internet connection is not required.

The Device ID must be set according to the external device.

Control Settings

Control Type: Adjustable Modbus TCP (Sun) ⚠

ELWA Number > 1: only 'Slave' selectable.

Control Source IP Address: 192 168 2 6

Device ID / Port: 1 502

Sign: - feed in

Meter Register: 1000 Int16

Scale Register: 1001 none

L1/L2/L3 Registers: 0 0 0

L1/L2/L3 Type: Int16

L1/L2/L3 Scale Registers: 0 0 0

L1/L2/L3 Scale Registers Type: none

Battery Charging Power Sign: + charging

Battery Charging Power Register: 0 Int16

Battery Charging Power Scale Register: 0 none

Control Status: Conn. to Power Meter, P=6

Power Timeout: 10

Control Target: -50 ⚠ W

Negative value means feed-in. Only change this value if you are familiar with the control strategy - read Help for more details.

Block start / stop hour: 0 0

Save

Control Settings

Control type: Adjustable Modbus RTU

AC-THOR Number > 1: only 'Slave' selectable.

Device ID: 1

Baud rate: 19200

Parity: even

Stop bits: 1

Register range: Holding registers

Sign: - feed in

Meter register: 1000 Int16

Scale register: 1001 none

L1/L2/L3 registers: 0 0 0

L1/L2/L3 type: Int16

L1/L2/L3 scale registers: 0 0 0

L1/L2/L3 scale registers type: none

Battery charging power sign: + charging

Battery charging power register: 0 Int16

Battery charging power scale register: 0 none

Control state: Conn. to Power Meter, P=2

Power timeout: 10

Control target: -50 ⚠ W

Negative value means feed-in. Only change this value if you are familiar with the control strategy - read Help for more details.


Block start / stop hour: 0 0


Save


Description of the data types:


Int16	16-bit integer value, two's complement representation
Int16-nc	16-bit integer value, magnitude sign representation (1st bit = sign)
Int32	32-bit integer value, two's complement representation
Int32-sw	32-bit integer value, two's complement representation, swapped words
Int32-nc	32-bit integer value, magnitude sign representation (1st bit = sign)
Int32-sw-nc	32-bit integer value, magnitude sign representation (1st bit = sign), swapped words
Float	32-bit float value
Float-sw	32-bit float value, swapped words

 This control types are currently not approved for hybrid systems with battery storage.

 With the settings "Adjustable Modbus TCP (Sunspec etc)", the IP address of the signal source must not change during operation (eg by a DHCP router), otherwise the AC-THOR loses the control signal.

 When controlled by an inverter, a feed-in meter is required in the system. The query of the inverter otherwise provides no data.

 We ask for your understanding that we cannot do any binding support for third-party products. For questions about third-party products, please contact the technical support of the respective company.

 Operation with battery may require additional control parameters. In this case, please contact the technical support of my-PV.

Measurement Settings

As an option, other measurements can be queried in the system in addition to PV excess measurement (see Control Settings) and visualise them on the my-PV.LIVE data platform. Available variables are Photovoltaic power, Battery power, EV Charging station power and Heat pump power.



These measured values have no relevance for the regular operation of the my-PV device!

If you are using the my-PV Meter to detect these values, you must enter the ID (serial number) of the device. You will find this number on the device.



If the measured values come from an inverter or Modbus meter, the required communication registers shall be set according to the manufacturer's description.



Measured value acquisition only works via network, not via Modbus RTU!



We ask for your understanding that we cannot do any binding support for third-party products. For questions about third-party products, please contact the technical support of the respective company.

Measurement Settings

Excess power in the grid feed-in point is already detected by the device configured for control (see Control Settings). In addition, these measured variables can optionally be detected for display in the my-pv.LIVE cloud. They have no relevance for the operation of the my-PV device.

Photovoltaic power

Measure source: Adjustable Modbus TCP

Modbus IP address: 0 | 0 | 0 | 0 | 0 | 0

Device ID / Port: 2 | 502

Register range: Holding registers

Meter register: 40499 | Int32

Scale register: 0 | none

L1/L2/L3 registers: 0 | 0 | 0

L1/L2/L3 type: Int16

L1/L2/L3 scale registers: 0 | 0 | 0

L1/L2/L3 scale registers type: none

Without PV power block device: Off On

Battery power

Measure source: none

EV Charging station power

Measure source: none

Heat pump power

Measure source: none

Save

Photovoltaic power

At the measuring point "Photovoltaic power" it is possible to block the my-PV device if the inverter does not produce any power. The operation for optional boost-backup is not affected by this.

EV Charging station power

If the "Interval target value" control function is used (see chapter "Control settings") and the "EV Charging station power" measuring point is also queried, it is possible to define an additional duration of the interval target value here. The interval target value is thus extended by this additional duration, provided the power at the charging station is at least above 500W at the end of the first interval.

EV Charging station power

Measure source:

my-PV Meter ID:

For the my-PV Power Meter, the ID (serial number) has 7 digits.
For the my-PV WiFi Meter, the ID (serial number) has 10 digits.

Additional duration of the interval target value when power is drawn (> 500W) from the charging station. s

Only relevant in connection with the interval target value under "Control Settings".

The positive effect of this is that the time of the higher target value of the control can be significantly shortened. It is regulated back to the original target value more quickly, which in turn ensures higher self-consumption.

EV Function

Although my-PV does not produce charging stations, there are various options for compatibility.



The EV Function is to be used exclusively for direct compatibility!

EV Function

EV Charging:

Off
 On

Direct compatibility with charging station

Direct compatibility exists if my-PV also performs the energy management of the charging station. However, it should be noted here that the power controllers from my-PV can only modulate the power on electric resistance heaters. This means that they never take over the power modulation of the charging station! However, the energy management system can tell the charging station how much photovoltaic surplus is available. As soon as the available charging current exceeds the limit of 6 amps, the charging station can adjust the power for vehicle charging accordingly. Although my-PV does not actually consider itself a Smarthome manufacturer, this type of energy management is possible with some types of the Keba brand. More information on compatible charging stations can be found [here](#).

Indirect compatibility with charging station

Indirect compatibility already exists when a higher-level energy management system has control over all consumers. For example, if a smarthome is able to control a charging station in addition to providing power to my-PV. In some cases, such systems also allow prioritisation of the different applications. Examples of such indirect compatibility include the SMA Sunny Home Manager, E3DC or Solar-Log. In this case, the my-PV device has nothing to do with the charging station. From my-PV's point of view, the wallbox manufacturer openWB also falls into the category of higher-level energy management, because the entire control and regulation strategy of the consumers is the responsibility of openWB, while the my-PV devices are only given the power output.

With both indirect and direct compatibility, an intelligent system coordinates the heat applications of my-PV and the charging station. There is also a third possibility.

Compatibility with charging station without common energy management.

This concerns the case where there are both applications, but they do not interact intelligently with each other through any energy management. This is the case when, for example, an inverter manufacturer can control its own charging station with solar power, but has not implemented the my-PV application as part of the energy management in its control system. In this case, my-PV exists as a separate controller quasi parallel to it and uses the PV surplus according to the power measurement from the house connection. It can happen that the my-PV application does not leave any surplus for the charging pole.

However, the interaction with the charging station is coordinated with the AC ELWA-E from firmware 00205.00 and with the AC-THOR from firmware a0020800. The explanation can be found in the section "Interval target value" in the chapter "Control settings", as well as in the section "EV Charging station power" in the chapter "Measured value settings".

Multi units

Multiple AC ELWA 2, AC ELWA-E, AC•THOR or AC•THOR 9s can be used in a network. Operation is based on the master / slave principle.



When using several units, the following things have to be considered:

- All devices must be connected to the router via network cable.
- Only one master can be assigned to a signal source and vice versa.
- A maximum of 10 slaves are possible per master.
- All slaves in the network must have different device numbers, even if these are assigned to different masters.
- **All devices must be assigned by permanent IP addresses.** This can be done in three ways:
 - In the web interface of the respective device (see IP Settings)
 - On the display of AC•THOR
 - By the router (recommended)


Settings on Slaves

For the slaves only the device numbers has to be specified (see Basic Settings). All other settings are only required on the master.

The screenshot shows the web interface for an AC ELWA-E 1 unit. The top navigation bar includes icons for signal strength, information, home, settings, and help, along with the unit name and IP address (192.168.2.12) and a language selector (DE/GB). The left sidebar lists menu items: Hot Water Boost, Legionella Protection, Time, Control Settings, Measurement Settings, EV Function, Multi Units, IP Settings, and Basic Settings. The main content area is for 'Control Settings'. The 'Control Type' dropdown is set to 'Slave'. Below it, the 'Control Source IP Address' is disabled. The 'Control Status' is 'No Control'. The 'Power Timeout' is set to 10. The 'Control Target' is set to -10. The 'Block start / stop hour' is set to 8 to 12. The 'Basic Settings' section at the bottom has the 'Number' dropdown set to 2, which is highlighted with a red box. The 'Fusetype' is set to 16 A. A 'Save' button is at the bottom.


As soon as an assignment has been made, further control settings are no longer possible or required. The IP address field is disabled and "Slave" appears in the Signal source field.

After a device search in the quick selection at the top right, the slave with the set number appears. Switching between the devices is possible here.




Settings on Master

Only for devices with number 1 (= master) the following display appears in the setup:



To make the settings for several devices on the master, first choose between **Synchron** and **Stratify**. In the case of synchronous charging, the power is evenly distributed to the master and its slaves. In the case of stratified charge, the devices are controlled one after the other according to their numbers, in each case until the set target temperature is reached.


After selection, please start the "Search for slaves" and activate the desired devices. Then save the setting.




Scanning is performed via UDP port 16124. Firewalls (or specific router settings) may prevent that other units can be found.

Cloud Mode

If your device has a device key, a connection to the data platform **live.my-PV.com** possible. You will find it glued on the enclosed assembly instructions.



Activate the cloud mode and save the settings.



Open the website **live.my-PV.com** and log in or register as a new user.



TIP: If you register for a new account you will receive an email with a confirmation link. If it does not appear in your inbox, it might be in your spam folder.

Privacy

Information on the privacy regulations can be found at www.my-pv.com.

Debug-Mode

In order to simplify the analysis in the case of possible connection problems, a debug mode can be activated in coordination with our technical support.

Help



In the web interface the button leads to the online Operation Manual which corresponds to the firmware version installed.

7. Frequency control

Explanation

With this signal source, an electric heater in an AC off-grid system is linearly supplied with excess PV power. The output of the AC•THOR is specified to the unit by a battery inverter through alteration of the grid frequency via mains connection. Wiring for communication is not required!

As soon as the frequency control is selected as the signal source, the measured value is shown on the display at the bottom right above the help button.



In boost backup mode, the battery must be expected to discharge!



TIP: Using several AC•THORs, each one may specify a different frequency range. This means that prioritisation of several heat generators is possible even without setting the multi-mode!

Specific settings for Frequency control

Frequency

The frequency range in which the adjustable power can be linearly fed can be altered. As lower limit (no power) and upper limit (maximum power) a range between 45 and 65 Hz is available. The factory settings are 50 Hz and 51 Hz. The frequency range must be at least 0.5 Hz!

Maximum power

The input of maximum power of the heating load is extremely important for this operating mode. This is why this setting possibility appears here in second place again, in addition to its normal position in the settings. See "General Settings" for details.

8. Potential-free input for external control

Control with 3.3 - 24 V DC voltage from external source

The AC•THOR can also be operated via an external PWM signal with variable power. The corresponding signal input is located at the 8-pin connector to which the temperature sensor is also connected.




This control is independent of the selected operating mode. If a PWM signal is present, all other control signals that might be available via a network are also overridden. If the boost backup mode is set at the AC•THOR, it remains valid.



When using several AC•THORs, a separate PWM signal is required for each device. Multimode is not possible with this control mode!

As soon as a PWM signal is present, it is displayed in percent on the bottom right of the display above the help button.




⚠ Observe the polarity of the DC voltage!

⚠ Without a temperature sensor, the AC•THOR will not switch off. This must then be done by the external signal source or by switching off by thermostat!

Control by potential-free contact

The AC•THOR can also be operated rigidly with maximum power via an external signal.




9. Modbus RTU connection for external control

⚠ Use shielded twisted pair wire!

⚠ RTU bus must be equipped with a 120 Ohm termination resistor!
(Not included in the scope of delivery)

⚠ When controlling via Modbus RTU, the operating mode M7 cannot be used!



10. Firmware update

Update from server



Internet access is required!

Manual Update

Display - Settings - Factory settings:

Check for new firmware: Start check for new updates manually. When a new version is available, it will be stored on the SD card. This procedure takes several minutes. The AC•THOR will operate normally during this period.

Start firmware update: if a newer software version is present on the SD card, the update can be started manually. After the update, the unit will be restarted automatically.

Start power firmware update: if a newer output unit software version is present on the SD card, the update can be started manually. After the update, the unit will be restarted automatically. With AC•THOR 9s the update for both power stages is started.

Update with SD card

This possibility is provided for installations without Internet access. Consultation with our technical support is necessary. To do this, send us the 16-digit serial number to support@my-pv.com.



Never remove the SD card while the unit is operational!



Never exchange an SD card between one unit and another! It contains data specific to the serial number of the unit.

11. Status codes

AC•THOR:	0.... Off
	1-8... Unit start-up
	9... Operation
	>=200 Fault conditions power stage
AC•THOR 9s:	0-15 ... internal states for support purposes
	>=200 Error states power stage 9s

12. Temperature sensors: Assignment and function (only with AC • THOR 9s)

Sensor assignment:

Operation mode	M1		M2	M3	M4	M5	M6	M7
Load priority	1-2-3	3-2-1	1-2-3	1-2-3	1-2-3	3-2-1	3-2-1	1-2-3
OUT-3	Sensor 1	Sensor 1	Sensor 1	Sensor 1	Sensor 1	Sensor 1 HW	Sensor 3 SH3	Sensor 1
OUT-2	Sensor 1	Sensor 2	Sensor 1	Sensor 1	Sensor 1	Sensor 3 SH2	Sensor 2 SH2	Sensor 1
OUT-1	Sensor 1	Sensor 3	Sensor 1	Sensor 1	Sensor 1	Sensor 2 SH1	Sensor 1 SH1	Sensor 1

Sensor function:

Operating mode	M1		M2	M3	M4	M5	M6	M7
Load priority	1-2-3	3-2-1	1-2-3	1-2-3	1-2-3	3-2-1	3-2-1	1-2-3
Sensor 1	Max / Min	Max / Min	Switch-over	Max / Min	Max / Min	Max / Min	Max / Min	Max
Sensor 2	none	Max / Min	none	none	none	Max / Min	Max / Min	PWM
Sensor 3	none	Max / Min	none	none	none	Max / Min	Max / Min	Min

13. Fault temperature sensors

0° Broken probe

85° Data disruption temperature sensor

14. Error messages on the Display

Error messages are only displayed on the home screen of the display. They are not shown in the web interface.

Error 101	No phase detected on the middle relay contact
Error 102	Temperature sensor 1 required for hot water boost backup Check if the sensor has been activated!
Error 103	Temperature sensor 1 required for this operating mode Check if the sensor has been activated!
Error 104	Temperature sensor 1 required for space heating Check if the sensor has been activated!
Error 105	Temperature sensor 1 required for hot water Check if the sensor has been activated!
Error 106	Controllable power < Load at relay
Error 107	Temperature sensor 2 required for space heating Check if the sensor has been activated!
Error 108	Temperature sensor 2 required for PWM Check if the sensor has been activated!

Error 109	Temperature sensor 1 required for legionella protection Check if the sensor has been activated!
Error 110	Firmware update unsuccessful communication fault with output unit Restart the unit
Error 111	Firmware update unsuccessful Problem with p-file. Switch off the unit. Insert SD card with p-file. See Operating instructions www.my-pv.com Restart the unit
Error 112	Temp sensor 3 required for hot water boost backup Check if the sensor has been activated!
Error 113	Output unit communication timeout. Restart the unit.
Error 114	Output unit stuck in bootloader. Restart the unit.
Error 115	Temperature sensors 2+3 required for spaceheating Check if sensors have been activated!
Error 116	Powerstage overload. Check installation
Error 117	Powerstage overtemperature. Device restarts after cool down.

15. Fault signals by the AC • THOR Logo

1x blinking ►	SD Card error
2x blinking ►	Firmware defective
3x blinking ►	Display error

my-PV GmbH
 Betriebsstrasse 12, A-4523 Neuzeug
www.my-pv.com

Subject to change without notice.

